



Spare parts for el. storage water heater Atlantic 10,15,30,50 liter




Ref. no.	Spare part name	for heater	pict.	
5014300	Gasket	10 - 50 L (LU)	A	399 091
5014305	6 holes flat gasket	10 - 50 L (LU)	B	399 285
5014310	heating element + anode + gasket	10 L	C	399 278
5014312	heating element + anode + gasket	10 LU	C	399 234
5014314	heating element + anode + gasket	15 L	C	399 279
5014316	heating element + anode + gasket	15 LU	C	399 277
5014312	heating element + anode + gasket	30 - 50 L	C	399 279
5014320	Anode	10 - 30 L (LU)	D	399 095
5014325	Anode	50 L	D	399 096
5014330	Thermostat	10 - 15 L	E	399 271
5014332	Thermostat	10 - 15 LU	E	399 283
5014338	Thermostat	30 - 50 L	E	399 272
5014342	Light	10 - 50 L (LU)	F	399 089
5014344	Blue knob	10 - 50 L (LU)	G	399 281
5014346	Protection cover	10 - 50 L (LU)	H	399 282
5014348	Wall bracket	10 - 50 L (LU)	I	399 286

Spare parts for el. storage water heater Atlantic 80,100 liter



ref. no.	Spare part name	Position on pict.	
5014100	Protection cover	7	022 328
5014204	Thermostat	109	070 070
5014104	Light	150	020 049
5014106	Heating element	211	060 429
5014107	6 holes flat gasket	221	040 353
5014108	Gasket	228	040 323
5014110	Anode for 80 L	354	040 193
5014112	Anode for 100 L	354	040 195
5014114	Safety valve (G 1/2, 7bar)		029 039
5014116	Plastic non - conducting socket G1/2		029 019

Spare parts for el. storage water heater Atlantic 150,200 liter



ref. no.	Spare part name	Position on pict.	Comment
5014200	Protection cover	30	022 286
5014202	attachment apparatus bracket	80	022 166
5014204	Thermostat	100	070 070
5014104	Light	150	020 049
5014206	Heating element	211	060 187
5014208	Gasket	228	040 158
5014210	Anode	354	040 166
5014114	Safety valve (G 1/2, 7 bar)		029 039
5014116	Plastic non - conducting socket G 1/2		029 019